WALT'S WATCH LAB

GMT AUTOMATIC WATCH GUIDE

WALTON custom watches

Read the arrow-tipped GMT hand on the 24-hour scale. If your bezel rotates, align 24 with 12 o'clock.



FIND YOUR CROWN POSITION

If the crown screws down, unscrew it first. Count each stop as you pull gently.



Fully in

Turn the crown to wind by hand, if supported.

First click

Adjust the GMT arrow or local hour with the method below.

Second click

Set the main time, including the minutes.

Crown positions and functions may vary by watch.

SET YOUR SECOND TIME ZONE



The GMT arrow moves

Caller GMT. Set local time at the second click. At the first click, set the arrow to your other zone's time. Some models quickset the date in the other direction. Quickset outside calendar-change hours.



The local hour hand jumps

Traveler GMT. At the second click, set home time using the GMT arrow and minutes. At the first click, jump the local hour to your destination. The date follows local midnight.

IMPORTANT TO REMEMBER



Close the Crown

Push the crown back against the case. If it screws down, gently screw it back into place.



Power Reserve

How long your watch runs off the wrist depends on the movement and how fully the spring is wound.

Starting a stopped watch If it winds only by motion, gently rock it in your hand.

WaltonCustomWatches.com/contact